LED PAR 64

Configuration (Standalone)

Set this product in one of the standalone modes to control it without a DMX controller.

• Connect this product to a suitable power outlet.

Never connect a fixture that is operating in any standalone mode, whether Static, Automatic, or Sound to a DMX string connected to a DMX controller. This is because fixtures in standalone mode may transmit DMX signals that could interfere with the DMX signals from the controller.

Sound-Active Mode

To enable the Sound-Active mode, do the following:

- 1) Press <MENU> repeatedly until P-- shows on the display.
- 2) Press <ENTER>.
- 3) Use **<UP>** or **<DOWN>** to select **P5** or **P6**.
- 4) Press <ENTER>.
- 5) Turn the music on and adjust the microphone sensitivity knob until the fixture starts reacting to the beat of the music.

The fixture will only respond to the low frequencies of the music (bass and drums).

Automatic Mode

To enable the Automatic Mode, follow the instructions below:

- 1) Press <MENU> repeatedly until P-- shows on the display.
- 2) Press <ENTER>.
- 3) Use **<UP>** or **<DOWN>** to select **P1~P4**.
- 4) Press <ENTER>.
- 5) Press <MENU> repeatedly until S-- shows on the display.
- 6) Use **<UP>** or **<DOWN>** to adjust the speed at which the program plays (S001~100).
- 7) Press **<ENTER>**.

Static Mode

To enable the Static mode, do the following:

- 1) Press <MENU> repeatedly until C-- shows on the display.
- 2) Press <ENTER>
- 3) Use **<UP>** or **<DOWN>** to select the pre-set colour (C1~C7).
- 4) Press <ENTER>.

Custom Static Colours

To enable the Custom Static Colours mode, do the following:

- 1) Press **<MENU>** repeatedly until **U--** shows on the display.
- 2) Press <ENTER>
- 3) Use <UP> or <DOWN> to select the desired colour: red (r-
- -), green (g--), or blue (b--).
- 4) Press <ENTER>
- 5) Use **<UP>** or **<DOWN>** to select the desired colour value (000~100).

NOTE: Selecting 000 will turn the colour off.

- 6) Press <ENTER> to continue to the next colour.
- 7) Repeat steps 5 to 7 until you create your desired colour.
- 8) Press **<ENTER>** to save the colour.

This mode allows a single SlimPAR™ 64 unit (the "master") to control the actions of one or more SlimPAR™ 64 units (the "slaves") without the need of a DMX controller. The master unit will be set to operate in either Automatic or Sound-Active mode, while the slave units will be set to operate in Slave

Mode. Once set and connected, the slave units will operate in unison with the master unit.

Configure the units as indicated below.

Slave units:

- 1) Press <MENU> repeatedly until 3-CH or 7-CH shows on the display.
- 2) Press <ENTER> to accept.
- 3) Use **<UP>** or **<DOWN>** to set the starting address to **d001**.
- 4) Press <ENTER>
- 5) Connect the DMX input of the first slave unit to the DMX output of the master unit.
- 6) Connect the DMX input of the subsequent slave units to the DMX output of the previous slave unit.
- 7) Finish setting and connecting all the slave units.

Master unit:

- 1) Set the master unit to operate in either Automatic or Sound mode, as previously indicated.
- 2) Make the master unit the first unit in the DMX daisy chain.

Master/Slave Mode